



User Manual



## Dash Camera

with front & rear recording plus GPS



Your Connection On The Road

KPT-1124



# CONTENTS

<b>1.0</b>	<b>CAUTION .....</b>	<b>6</b>
1.1	PRODUCT INFORMATION .....	8
<b>2.0</b>	<b>INTRODUCTION .....</b>	<b>8</b>
2.1	PACKAGE CONTENTS .....	9
2.2	PRODUCT OVERVIEW .....	10
<b>3.0</b>	<b>BUTTON FUNCTIONS .....</b>	<b>11</b>
<b>4.0</b>	<b>GETTING STARTED .....</b>	<b>12</b>
4.1	INSERTING A MICRO SD CARD .....	13
4.2	REMOVING A MICRO SD CARD .....	13
4.3	INSTALLING THE KPT-1124 .....	14
4.4	CONNECTING TO POWER .....	15
4.5	INSTALLING THE REAR CAMERA .....	16

4.5.1	INSTALLATION GUIDE.....	16
4.5.2	REAR CAMERA WIRING DIAGRAM .....	17
4.5.3	REAR CAMERA FEATURES.....	18
<b>5.0</b>	<b>POWERING ON/OFF .....</b>	<b>19</b>
5.1	AUTO POWER ON/OFF.....	19
5.2	MANUAL POWER ON.....	19
5.3	MANUAL POWER OFF .....	19
5.4	RESETTING THE DASH CAMERA .....	19
<b>6.0</b>	<b>INITIAL SETTINGS .....</b>	<b>20</b>
6.1	FORMATTING THE INSERTED MICRO SD CARD.....	20
<b>7.0</b>	<b>SETTING THE TIME AND DATE .....</b>	<b>21</b>
<b>8.0</b>	<b>VIDEO MODE .....</b>	<b>22</b>

<b>9.0</b>	<b>INTERFACE .....</b>	<b>22</b>
9.1	VIDEO MODE .....	23
9.2	SETUP MENU.....	23
<b>10.0</b>	<b>VIDEO MENU .....</b>	<b>24</b>
<b>11.0</b>	<b>PLAYBACK.....</b>	<b>27</b>
<b>12.0</b>	<b>SOFTWARE PLAYBACK .....</b>	<b>28</b>
<b>13.0</b>	<b>USING MICRO SD CARD READER .....</b>	<b>29</b>
<b>14.0</b>	<b>WARRANTY TERMS &amp; CONDITIONS .....</b>	<b>29</b>
14.1	INDEMNITY.....	30
14.2	WARRANTY AND WARRANTY DISCLAIMER .....	31
14.3	LIMITATIONS OF KPT-1124 LIABILITY .....	33
<b>15.0</b>	<b>NOTES.....</b>	<b>35</b>

## 1.0 CAUTION

- Ensure you are using your Dash Camera within your country's road laws. Please make sure you are familiar with your local road legislation before use.
- Avoid leaving your Dash Camera in direct sunlight for extended periods of time in unventilated spaces.
- Please set up the time and date before you use this device to record.
- The notifications given by the Dash Camera are suggestions only, please drive to the actual conditions.
- The results of GPS positioning are for reference only. The Dash Camera will lose GPS positioning abilities when the signal is blocked (e.g. driving through tunnels, enclosed car parks).
- GPS positioning accuracy may vary depending on weather and surroundings such as dense cities, tunnels or forests. GPS satellite signals cannot pass through most solid materials. Tinted windows may also affect the GPS signal.
- The values displayed in this system, such as speed, position and the distance warning, may be affected by the surrounding environment.
- The system is to be used only for non-commercial use, within the limits permitted by your country's relevant laws.

- Avoid using the Dash Camera near any devices that emit radio interference (e.g. microwave ovens). It is considered normal operation for the Dash Camera to get warm during use.

## **NOTES ON INSTALLATION**

- It is advised that the Dash Camera is installed near the rear view mirror, at the top centre of the windshield for optimal operation.
- Make sure that the lens is within range of the windscreens wiper to ensure a clear view when it rains.
- Do not touch the lens with your fingers. Fingerprints left on the lens will result in unclear videos or photos. If photos or videos are blurred, please clean the lens gently with a microfibre cloth.
- Do not install the device on a tinted window. Doing so may damage the tint film and restrict the Dash Camera's GPS signal
- Make sure that the installation position does not hinder or block the field of view or GPS signal.
- Only use the included cable to power the Dash Camera.
- The KPT-1124 is designed to be constantly connected to the included power supply.

## 1.1 PRODUCT INFORMATION

For the latest manual and product updates please visit our websites:

[www.kapture.com.au](http://www.kapture.com.au) or [www.kapturecam.co.nz](http://www.kapturecam.co.nz)

## 2.0 INTRODUCTION

Thank you for purchasing a KPT-1124 Dash Camera. Please read through the instructions before attempting to install or use this product.

This User Guide is designed to assist with the day to day operation of the KPT-1124.

Before attempting to use or install your KPT-1124, please ensure you have read and understood all of the safety notes below:

- Do not expose your KPT-1124 to liquids, excessively dusty conditions or temperatures exceeding 60°C.
- Only use the included cables to power and charge the KPT-1124.
- Please do not attempt to adjust the KPT-1124 position or settings whilst you are driving your vehicle.
- Please clean the windshield thoroughly, removing all dust and dirt particles before fixing the adhesive mount.

- Since the mount sticks on the windshield with the 3M mount, please ensure that the camera is best located to capture the maximum view.
- We suggest you power-on the Dash Camera and test the playback image on screen prior to removing the 3M tape for installation.
- Only remove the 3M tape when you are satisfied that the Dash Camera placement and image position are delivering the best possible image and view of the road ahead.
- Ensure you are using your KPT-1124 within your country's road laws. Please make sure you are familiar with your local road legislation before use.

## 2.1 PACKAGE CONTENTS



Dash Camera  
with GPS x1



12/24V  
Adaptor x1



User Manual x1



Spare 3M  
Adhesive x1




Rear Camera  
with 8M Cable x1



Electrostatic  
Film x2

## 2.2 PRODUCT OVERVIEW



1. Type-C Power Port
2. AV-Rear Camera In
3. Display
4. 3M Adhesive
5. Mic
6. Front Lens
7. Reset
8. Mode/Menu Button
9. Up Button
10. Down Button
11. Power/Ok Button
12. Speaker
13. Micro Card Slot

## 3.0 BUTTON FUNCTIONS

### MENU & MODE BUTTON

Hold and press the M button to switch between video Mode/Playback Mode.

Press the 'M' Button to enter into the menu settings.

### POWER/OK BUTTON

Press and hold the Power Button to Power Off the Device.

(Please note, when connected to power, the KPT-1124 will automatically start recording).

Press the OK Button to take a photo during recording.

Press the OK Button to play/pause the current video in Playback Mode.

Press the OK Button to confirm the selection in menu.

### DISPLAY SWITCH, UP BUTTON

In the Settings menu use the Up Button to toggle between settings.

Press Up Button to switch the display.

### **DOWN BUTTON**

In the Settings menu, use the Down Button to toggle between settings. Press the Down Button to turn the inbuilt microphone ON/OFF.

### **RESET BUTTON**

Press to reset to factory settings.

### **MIC**

Microphone Position

### **TF CARD SLOT**

Micro SD Card Slot. Please use Maximum 256GB , U1 and above.

### **USB INTERFACE**

Type-C USB socket to connect with Power Cable provided.

## **4.0 GETTING STARTED**

## **4.1 INSERTING A MICRO SD CARD**

With the Dash Camera turned off and the screen facing towards you, insert Micro SD Card (not included) in the slot on the left side of the KPT-1124 with the text on the Micro SD card away from you. Push the memory card in until a click is heard.

## **4.2 REMOVING A MICRO SD CARD**


Ensure that the KPT-1124 is powered off, and with your thumbnail press in the Micro SD Card until a click is heard. The Micro SD Card will eject when released.

### **NOTE:**

- Micro SD Card is not included.
- Do not remove or insert a Micro SD card while the Dash Camera is turned on as this may damage the Micro SD card or corrupt the card's stored data.
- Please use a U1 or higher rated Micro SD card with a maximum capacity of 256GB.
- Please format the Micro SD card before initial use. (See section 6.1 for instructions on Formatting your Micro SD card).
- When removing the Micro SD card, be careful as the card may eject quickly.

#### 4.3 INSTALLING THE KPT-1124

1. Connect the window mount to the top of the Dash Camera and rotate the locking nut (See Fig 1 on page 14) clockwise until it is tight.
2. Please follow the instructions on page 6 before continuing.
3. Remove the protective stickers from the Dash Camera and the 3M Mount.
4. Press the mount base firmly against the windscreen and hold for 30 seconds.
5. Insert the power cable adaptor into the Dash Camera power socket.



**NOTE:**

- It is advised that the KPT-1124 is installed in the centre of the windscreen behind the rearview mirror.

(Fig .1) Installing the KPT-1124

## 4.4 CONNECTING TO POWER

Only use the included charger to power and charge the Dash Camera.

1. Once the Dash Camera is securely installed on your vehicle's windscreen, plug the DC Power Plug into your vehicle's cigarette lighter.
2. Run the power cable along the top and side of the windscreen and behind your glove box. Plug the Type-C USB plug into the Dash Camera and the DC Power Adaptor into your cigarette lighter port. (See Fig 1 on page 14.)

### NOTES:

- It is recommended that the Dash Camera is installed behind your vehicle's rear-view mirror. It is highly recommended you format your Micro SD card the first time it is inserted. Please follow the Micro SD card Formatting instructions on page 20 Section 6.1. Quick Format.
- Make sure that the Dash Camera view is not obstructed by any window tint or any other objects.
- The KPT-1124 is designed to be constantly powered by the included DC Power Plug.

## 4.5 INSTALLING THE REAR CAMERA

### 4.5.1 INSTALLATION GUIDE

1. **Optional:** select the electrostatic film from the box and install it on the rear windshield in the recommended position as shown below. Please wipe glass before installation and push out the bubbles between the static film and the glass before installation.
2. Remove the protective film from the rear camera base bracket and select either the top or the bottom of the rear window to position the rear camera.
3. Press down on the base of the bracket by hand for 30 seconds to ensure that the sticker adhesive has attached to the electrostatic film.

Connect the rear camera to the KPT-1124 using the cable provided. Either run the cable through the roof lining or under the carpet underlay as shown below. The rear camera can rotate 360° degrees depending on the position and type of installation method.

**Method 1:** thread the rear camera cable along the top of the roof lining and connect it to the Dash Camera.


**Method 2:** lift up the car carpet and run the rear camera cable along the underlay of the carpet and connect it to the Dash Camera.

4. Adjust camera by rotating the barrel until it is capturing the entire road.

**NOTE:**

- While viewing your live footage on the DVR or on the Dash Camera, the rear camera will show the true rearview image where the license plates of vehicles behind your vehicle are inverted. Actual recorded images are horizontally flipped to capture the license plate correctly.

#### 4.5.2 REAR CAMERA WIRING DIAGRAM



#### 4.5.3 REAR CAMERA FEATURES

After successfully installing and connecting the rear camera into the main Dash Camera, the rear camera's image will be displayed on the Dash Camera's screen.

Both Cameras will instantaneously start recording after the Dash Camera is powered ON.

Front camera image will now be displayed on your Dash Camera's screen, you can switch between them by pressing the Up Button.

#### THE DISPLAY CAN SWITCH BETWEEN:

1. Full front camera view
2. Full rear camera view
3. Half front camera and half rear camera view

#### NOTE:

- The KPT-1124 is designed to be constantly powered by the included DC Power Plug.

## **5.0 POWERING ON/OFF**

### **5.1 AUTO POWER ON/OFF**

When the Dash Camera is correctly installed and connected to your vehicle's power supply, the Dash Camera will automatically power up and start recording when the vehicle accessories are activated.

### **5.2 MANUAL POWER ON**

Hold the  Power Button on the bottom right hand side of the camera until the KPT-1124 start up screen appears.

### **5.3 MANUAL POWER OFF**

Hold and press  Power Button. After powering down the device, please wait for 10 seconds before turning the Dash Camera back on.

### **5.4 RESETTING THE DASH CAMERA**

If the Dash Camera does not function normally, try restarting the Dash Camera. To restart the Dash Camera, using a small pin, press and hold the Reset button on the bottom side of the camera.

## 6.0 INITIAL SETTINGS

Before using the Dash Camera we recommend Formatting the Inserted Micro SD Card and setting the correct Time and Date.

### 6.1 FORMATTING THE INSERTED MICRO SD CARD

Formatting the Micro SD card will delete all information on the inserted Micro SD Card and prepare the card for use with the Dash Camera.

1. Press the  Button to enter the Settings Menu.
2. Use the  and  Buttons to navigate the Settings Menu and highlight the Format setting, then press the right  to select.
3. Select Quick Format and press the  Button.
4. Press the  Button to confirm.

#### NOTES:

- Formatting your Micro SD Card will delete all files from the card. Once these files have been deleted you will not be able to recover them.

## 7.0 SETTING THE TIME AND DATE

Setting the Time and Date allows you to stamp your footage with the time and date as a reference. Date and time stamps are important, especially when using your footage in an insurance claim.

1. Press the  Button to enter the Settings Menu.
2. Use the OK Button to navigate the Settings Menu and highlight the Date/Time setting.
3. Use the  and  Buttons to edit the selected digit and the  button to confirm and progress to the next digit. The final field will set the format that the time will be presented in, and pressing the  Button with this field highlighted will save the date and revert to the settings menu.


### NOTES:

- Once the time and date is set, it can be stamped onto your footage using the Date Stamp setting.

## 8.0 VIDEO MODE

When the Dash Camera is powered ON the video screen will start by default. In this screen, recording will automatically start. To access the Video Menu, press the  Button.

## 9.0 INTERFACE



## 9.1 VIDEO MODE

1. **Duration:** 00:01 Loop Recording timer.
2. **Date:** (01/01/2024)
3. **Time:** (00:01)
4. **Microphone:** turns microphone on or off.
5. **Battery:** indicates power connected.

## 9.2 SETUP MENU

1. Press the  Button to enter into the Settings Menu.
2. Press the  and  Buttons to select the setting you wish to change.
3. Press  Button on your selected option.

## 10.0 VIDEO MENU

Menu	Setting Options	Description
Resolution	4K/2K	<p>Please note, higher resolution gives your footage more detail but uses more storage space.</p> <p>Lower resolution saves storage space.</p> <p><b>Default: 4K</b> (Applies to front camera only, rear camera is set to 1080 P)</p>
Loop Recording	1min/2mins/3mins	<p>Loop Recording defines the length of time the unit records before creating a new file.</p> <p><b>Default: 1 Min</b></p>
Audio Recording	On/Off	<p>Turning this setting off mutes the built in microphone.</p> <p><b>Default: On</b></p>
G-sensor	Off/Low/Medium/High	<p>Adjust the sensitivity of the G-sensor.</p> <p>High is the highest sensitivity and Low is the lowest.</p> <p><b>Default: Low</b></p>
Parking Monitor	On/Off	<p>Requires a 3-wire hardwire kit (KPT-SHWK, not provided).</p> <p>When park mode is turned on and the car detects the engine is off, it enters stand-by state: it will be turned on and record video when an impact is detected.</p>

Menu	Setting Options	Description
Date and time stamp		Select On/Off to have the date and time stamped on the recorded Video. <b>Default: On</b>
GPS Stamp	On/Off	Select On/Off to have the speed and location coordinates stamped on the recorded Video. <b>Default: On</b>
License Plate Stamp		Input your car number plate and it will be stamped on the recorded footage.
Screen Saver	Off/10S/30S/60S	Turns off display when turned On. Dash cam will continue recording. <b>Default: Off</b>
Beep Sound		Mutes control for Button beeps. <b>Default: On</b>
Speaker	Off/Low/Medium/High	To change the sound output from inbuilt speaker. <b>Default: Off</b>
Power On Sound		To turn On/Off sound when the dash camera is powered on. <b>Default :Off</b>
Date and Time Setting		Set Date and Time.

Menu	Setting Options	Description
<b>GPS info</b>		Provides an indication on GPS signal strength.
<b>Format SD Card</b>		Format the inserted Micro SD Card, deleting all photos, videos and data.
<b>Factory Settings</b>		Restore default factory settings.
<b>About Dash Cam</b>	KPT-1124	Displays the installed firmware version.
<b>Time-lapse On/Off</b>	Off/1S/2S/3S	This menu will appear after connecting a 3-wire hardwire kit (KPT-SHWK, not provided). When time-lapse mode is turned on (1S/2S/3S) and the car detects the engine is off, the recording will be done in time-lapse mode. This is to save memory space when the car is parked.
<b>Time-lapse Duration</b>	Off/12H/24H/48H	This menu will appear after connecting a 3-wire hardwire kit (KPT-SHWK, not provided). To select the duration of the time-lapse mode when the car is parked. It will stop recording after the time-lapse duration. If set to OFF, the time-lapse mode will remain on until cut off voltage is detected.

## 11.0 PLAYBACK

File Management				
DIRECTORY	VIDEO	VIDEO_ROCK	PHOTO	
FRONT	 20240110_182157_f.ts	 		
REAR	 20240110_181557_f.ts	 		
	 20240110_181449_f.ts	 		


1. Press and hold  button to enter Playback Mode.
2. Press Up and Down buttons to select desired file folders to be played back and then press  button to confirm.
3. Press the  and  buttons to select the desired file to be played back.
4. Press  button to playback the selected video file and then press again to pause.

## 12.0 SOFTWARE PLAYBACK

The GPS Add-On unit will record your vehicle's speed and GPS location for playback alongside your footage when viewed on a computer.

GPS player will be copied on the Micro SD card when correctly formatted in the KPT-1124 To view images from Dash Camera, you will need to remove the Micro SD Card and transfer the files to your computer using a Micro SD Card Slot or compatible USB adapter.

Once files have been transferred to your computer, please select the folder and select the file you wish to view or playback.



## **13.0 USING MICRO SD CARD READER**

Please insert the micro SD card in to the reader and plug into your PC to view recorded footage. Micro Sd card is not provided.

## **14.0 WARRANTY TERMS & CONDITIONS**

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty is provided in addition to your rights under the Australian Consumer Law.

Directed Electronics Australia Pty Ltd (Directed Electronics) warrants that this product is free from defects in material and workmanship for a period of 12 months from the date of purchase or for the period stated on the packaging. This warranty is only valid where you have used the product in accordance with any recommendations or instructions provided by Directed Electronics.

This warranty excludes defects resulting from alterations of the product, accident, misuse, abuse or neglect. In order to claim the warranty, you must return the product to the

retailer from which it was purchased or if that retailer is part of a National network, a store within that chain, along with satisfactory proof of purchase. The retailer will then return the goods to Directed Electronics.

Directed Electronics will repair, replace or refurbish the product at its discretion. The retailer will contact you when the product is ready for collection. All costs involved in claiming this warranty, including the cost of the retailer sending the product to Directed Electronics, will be borne by you.

Ph: +61 03 8331 4800 | Email: [info@kapturecam.com.au](mailto:info@kapturecam.com.au)

#### **14.1 INDEMNITY**

You agree to defend, indemnify and hold harmless KPT-1124 and its subsidiaries and affiliates from and against any and all claims, proceedings, injuries, liabilities, losses, costs and expenses (including reasonable legal fees), including but not limited to, claims alleging negligence, invasion of privacy, copyright infringement and/or trademark infringement against KPT-1124 and its subsidiaries and affiliates, relating to or arising out of your breach of any provision of these terms, your misuse of KPT-1124 products or its services, or your unauthorised modification or alteration of products or software.

## 14.2 WARRANTY AND WARRANTY DISCLAIMER

KPT-1124 has a limited warranty, whereby KPT-1124 warrants to you and only to you that this KPT-1124 product will be free from defects in materials and workmanship for one (1) year from the date of your purchase (unless a longer warranty period is required by law). The specifics of this KPT-1124 limited warranty are covered in this manual.

To the extent possible under governing law, other than the above product warranty for the KPT-1124 product you understand and agree that the KPT-1124 products and services are provided on an "as is" and "as available" basis. KPT-1124 makes no warranty that the KPT-1124 products and services will meet your requirements or that use of the KPT-1124 products and services will be uninterrupted, timely, secure or error-free. Nor does KPT-1124 make any warranty as to the accuracy or reliability of any information obtained through KPT-1124 (including third party content), that any defects in the KPT-1124 products or services be corrected or that the KPT-1124 products or KPT-1124 services will be compatible with any other specific hardware or service. Further, KPT-1124 does not warrant that KPT-1124 products or services or KPT-1124 servers that provide you with data and content are free of viruses or other harmful components.

KPT-1124 also assumes no responsibility for and shall not be liable, for any damages caused by viruses that may infect your KPT-1124 product or software. In the event of any loss, damage or injury, you will not look to KPT-1124 to compensate you or anyone else.

You release and waive for yourself and your insurer all subrogation and other rights to recover against KPT-1124 arising as a result of the payment of any claim for loss, damage or injury. KPT-1124 equipment and services do not cause and cannot eliminate occurrences of certain events and KPT-1124 makes no guarantee or warranty, including any implied warranty of merchantability or fitness for a particular purpose or that KPT-1124 equipment and services provided will detect or avert such incidents or their consequences.

KPT-1124 does not undertake any risk that you or property, or the person or property of others, may be subject to injury or loss if such an event occurs. The allocation of such risk remains with you, not KPT-1124. Other than the above product warranty for KPT-1124 products, its suppliers disclaim all warranties of any kind, whether express, implied, or statutory, regarding the KPT-1124 products and services, including any implied warranty of title, merchantability, fitness for a particular purpose, or non-infringement of third-party rights. Because some jurisdictions do not permit the exclusion of implied warranties, the last sentence of this section may not apply to you.

KPT-1124 hereby further expressly disclaims all liability for any claims for service failures that are due to normal product wear, product misuse, abuse, product modification, improper product selection or your noncompliance with all applicable federal, state or local laws. This warranty and warranty disclaimer give you specific legal rights, and you may have other rights that vary by state, province, or country. Other than as permitted

by law, KPT-1124 does not exclude, limit or suspend other rights you have, including those that may arise from the nonconformity of a sales contract. For a full understanding of your rights, you should consult the laws of your state, province, or country.


#### **14.3 LIMITATIONS OF KPT-1124 LIABILITY**

Under no circumstances will KPT-1124 be liable in any way for any content, including, but not limited to, the loss of content, any errors or omissions in any content, or any loss or damage of any kind incurred in connection with use of or exposure to any content posted, emailed, accessed, transmitted, or otherwise made available via KPT-1124. KPT-1124 liability for damages, especially for breach of duty or obligation, delay in performance, non-performance, or malperformance shall be precluded, except when these are due to negligent breaches of any significant contractual duty or obligation on the part of KPT-1124. Any liability for negligence is limited to direct losses usually and typically foreseeable in such case.

Should the claim for damages be based on wilful or grossly negligent breach of contractual duty or obligation on the part of KPT-1124, the preclusion and limitation of liability mentioned in the preceding sentences will not apply. The preceding preclusion and limitation of liability will also not apply to claims for damages arising out of loss of life, bodily injury or health impacts for which KPT-1124 may be liable, or for non-contractual liability.

Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Additionally, this provision is not intended to limit KPT-1124's liability in the event of KPT-1124's wilful or intentional misconduct.

## 15.0 NOTES



# Your Connection On The Road

[www.kapture.com.au](http://www.kapture.com.au) | [www.kapturecam.co.nz](http://www.kapturecam.co.nz)



All Images, Information and Content are Copyright © 2025  
Directed Electronics Australia Pty Ltd. All Rights Reserved.



ANOTHER  
DIRECTED  
BRAND

**DIRECTED**<sup>®</sup>  
AUSTRALIA & NZ

[www.directed.com.au](http://www.directed.com.au)  
[www.directed.co.nz](http://www.directed.co.nz)