



Motorbike Smart Monitor
With front & rear cameras



CONTENTS

1.0	CAUTION	5
1.1	PRODUCT INFORMATION	6
2.0	INTRODUCTION	6
2.1	IN THE BOX.....	7
3.0	INSTALLATION INSTRUCTIONS	7
3.1	INSTALLATION WIRING OVERVIEW.....	7
3.2	INSTALLATION DIAGRAM	9
4.0	MOUNTING THE DEVICE	11
5.0	CAMERA CONNECTION	12
6.0	HOME SCREEN OVERVIEW	13
7.0	HOME SCREEN OVERVIEW	14
7.1	MICRO SD CARD INSTALLATION	14
8.0	DASH CAMERA	17
9.0	APPLE CARPLAY	19
10.0	ANDROID AUTO	20

11.0	SETTINGS	21
11.1	SYSTEM SETTING	22
11.2	CAMERA SETTING.....	23
11.3	BRIGHTNESS ADJUSTMENT	25
11.4	FORMATTING MICRO SD CARD	26
11.5	FACTORY RESET	26
11.6	ABOUT	26
12.0	HANDLEBAR CONTROLLER FUNCTIONS	27
13.0	WARRANTY TERMS & CONDITIONS	28
13.1	INDEMNITY	29
13.2	WARRANTY AND WARRANTY DISCLAIMER.....	29
13.3	LIMITATIONS OF KPT-W62B LIABILITY	31
14.0	NOTES.....	32

1.0 CAUTION

- Ensure you are using your Dash Camera within your country's road laws and that you're familiar with the local road legislation before use.
- Avoid leaving your Dash Camera in direct sunlight for extended periods of time in unventilated spaces.
- Remember to set up the time and date before you use this device to record. The notifications given by the Dash Camera are suggestions only, please drive to the actual conditions.
- The Dash Camera is to be used only for non-commercial use, within the limits permitted by your country's relevant laws.
- Avoid using the Dash Camera near any devices that emit radio interference (e.g. microwave ovens). It is considered part of normal operation for the Dash Camera to get warm during use.

- **NOTES ON INSTALLATION:** The Monitor is best installed near the rear view mirror, at the top centre of the windshield for optimal operation.
- Do not touch the lens with your fingers. Fingerprints left on the lens will result in unclear videos or photos. If photos or videos are blurred, please clean the lens gently with a microfibre cloth.
- Only use the included cables to power the Monitor.
- The KPT-W62B is designed to be constantly connected to the motorbike's power supply.

1.1 PRODUCT INFORMATION

For the latest manual and product updates please visit our websites:

www.kapturecam.com.au or www.kapturecam.co.nz

2.0 INTRODUCTION

Thank you for purchasing a KPT-W62B Dash Camera. Please read through the instructions before attempting to install or use this product.

This User Guide is designed to assist with the day to day operation and before attempting to use or install your Dash Camera, please ensure you have read and understood all of the safety notes below:

- Do not expose your Dash Camera to liquids, excessively dusty conditions or temperatures exceeding 60°C.
- Only use the included cables to power and charge the KPT-W62B.
- Please do not attempt to adjust the Dash Camera position or settings whilst you are riding your motorbike.


2.1 IN THE BOX

- 1 x Smart Monitor
- 1 x Power Cable
- 1 x Front Camera
- 1 x Rear Camera
- 1 x Handlebar Controller
- 1 x Silicone Gasket
- 1 x Bracket
- 1 x User Manual
- 2 x Allen Keys
- 7 x Screws

3.0 INSTALLATION INSTRUCTIONS

3.1 INSTALLATION WIRING OVERVIEW


- **Red Wire** → ACC Terminal (Accessory Power)
- **Yellow Wire** → Motorcycle Battery Positive Terminal
- **Black (Ground) Wire** → Motorcycle Battery Negative Terminal
- **CU/SL Connectors** → Front and Rear Cameras
- **Handlebar Controller** → Connect to Motorcycle CarPlay Screen
- **Power Cord** → Connect ACC and Ground



Please ensure wires are long enough to avoid restricting steering movement and damaging connectors.

3.2 INSTALLATION DIAGRAM

1. Connect motorbike CarPlay Monitor following the Installation Wiring Overview 3.1 (Pages 7 & 8) and mount the Monitor as shown at 4.0 (Pages 11 & 12)
2. Connect ACC power supply to the Monitor with the Red Power Wire and run it securely under the petrol tank to the bike's positive battery terminal and connect. Then, connect the Black Ground Wire to the Monitor and run it securely under the petrol tank to the bike's negative battery terminal and connect.
3. Attach Handlebar Controller where safest for easy access. Connect wire and run it securely back to Monitor and connect.
4. Attach front camera securely to the bike to provide a clear view of the road ahead. Connect wire to camera and run it securely back to Monitor and connect.




5. Attach rear camera securely to bike to provide a clear view of the road behind.
Connect wire to camera and run it securely back under seat and petrol tank to Monitor and connect.
6. At every step, secure and tuck away any excess wiring safely using fasteners such as cable ties - leaving enough wiring length to avoid restricting steering movement and damaging connectors.

NOTE:

Working with your motorcycle's power system can be hazardous to you and your bike if you are not familiar with such tasks. If you have any doubts regarding the installation of the front and rear cameras and monitor, it is recommended that you seek a qualified motorbike technician for assistance.

4.0 MOUNTING THE DEVICE


1. Attach the mount to handlebar using the Allen Key provided.
2. Clamp the connecting rod to the mount.
3. Secure the device to the support bracket with four screws.
4. Installation complete.





5.0 CAMERA CONNECTION

1. Connect the front and rear camera cables to the Smart Monitor as shown. For more detailed instructions refer to 3.2 Installation Diagram (Page 9 & 10)



6.0 HOME SCREEN OVERVIEW



1. Date & Time: Displays current time and date.
2. Brightness Button: Adjusts screen brightness.
3. Display Button: Turns off screen; tap anywhere to wake.
4. Apple CarPlay: Tap to connect an iPhone.
5. Android Auto: Tap to connect an Android phone.
6. Camera: Tap to enter video recording interface.
7. System Settings: Access device settings.
8. Micro SD Card Indicator
9. Audio Recording Status
10. Video Recording Indicator

7.0 HOME SCREEN OVERVIEW

7.1 MICRO SD CARD INSTALLATION

INSTALLING THE CARD

Micro SD card slot is concealed under the protective waterproof plate and gasket. Remove the screws with a Phillips Screwdriver - not provided.


Insert the Micro SD card with the chip side facing up until you hear a click.


After inserting micro SD card, ensure the gasket and protective plate is securely screwed and sealed into place.

NOTE: Please ensure the screws are tightly secured as water seepage can damage the monitor.


FORMATTING THE CARD

NOTE: Formatting will erase all data on the Micro SD card and is irreversible.





1. Press the **Settings** icon.




2. Press the **Format SD** icon.

Your Micro SD card will now begin to format.

8.0 DASH CAMERA

After inserting and formatting the Micro SD card:

- The red dot indicator shows the camera is recording.
- Tap **Dash Camera** icon to access camera function.




1. Exit current page
2. Toggle audio recording
3. Capture a photo
4. Start/Stop recording
5. Open settings
6. Lock current video (prevents overwriting)

NOTE:

7. Slide right: Enter playback mode.
8. Slide up/down: Adjust preview angle or brightness.
9. Slide up/down: Adjust preview angle or brightness.
10. Slide left: Switch preview mode.

9.0 APPLE CARPLAY

1. Tap the **CarPlay** icon.




2. Enable Bluetooth on your iPhone.
3. Pair with **KPT-W62B_*******.
4. Accept the CarPlay prompt on your phone.
5. CarPlay connects via Wi-Fi automatically.

NOTE:

- First-time connection may take longer.
- Requires iOS 13.0 or higher.

10.0 ANDROID AUTO

1. Tap the **Android Auto** icon.




2. Enable Bluetooth on your Android device.
3. Pair with **KPT-W62B_*******.
4. Accept Android Auto authorisation prompt.
5. Connection complete.

After first connection, it will show Connected and display the Android Auto menu.

NOTE:


- First-time connection may take longer.
- Requires Android 11.0 or higher.

11.0 SETTINGS




Tap the **Settings** icon to access:

- Brightness
- CarPlay / Android Auto
- Camera Settings
- Bluetooth Pairing
- System Setting



11.1 SYSTEM SETTING

1. Tap System Setting icon to access:



FLOATING KEY

- Toggle On/Off
- Default: ON

AUTO LCD OFF

- Automatically turns off display
- Options: Off / 10s / 30s / 60s
- Default: Off

To save your selection, tap the  button.

Memory



- Tap **Memory** icon to display the total capacity and available space.

Date & Time

- Tap **Date Time** icon to set date and time display.

11.2 CAMERA SETTING


1. Tap **Camera Setting** to access:



Loop Recording

- Set video segment length: 60s / 120s / 300s
- Default: 60 seconds

Loop recording allows you to define the duration of each recorded clip. Here's how to set the clip length:

- A. Tap the **Camera Setting** icon to enter menu.
- B. Tap Loop Recording icon.
- C. Tap the icon to choose video clip length as 60s, 120s or 300s.
- D. To save your selection, tap the  button.

Default Setting: 60 seconds

1. Rear Camera Mirror

Tap **Rear Cam Reverse/OFF** to Toggle mirror view.

Default: Off



2. Microphone

Tap **Microphone** icon to toggle microphone on /off.

Default: On

11.3 BRIGHTNESS ADJUSTMENT


Tap **Brightness** icon to to adjust levels.



Brightness adjustment is divided into three modes:

- **Day Mode** – Manual adjustment.
- **Night Mode** – Manual adjustment.
- **Default:** Day Mode.

11.4 FORMATTING MICRO SD CARD



Tap **Format SD Card** icon to format card.

NOTE: Formatting Micro SD Card will delete all files from your Micro SD Card.

11.5 FACTORY RESET

- Tap **Factory Reset** icon to enter restore factory settings.
- Resets all settings to default.

11.6 ABOUT

- Tap **About** icon to display firmware and Bluetooth version details.

12.0 HANDLEBAR CONTROLLER FUNCTIONS

1. Photo Capture/Snapshot

- **Short press:** Switch front/rear camera preview.
- **Long press:** Capture photo.

2. Answer/End Call

- **Short Press:** Answer or end call.
- **Long Press:** Hang up call (not supported in Android Auto).

3. Interface Switch/Lock touch panel

- **Short Press** – Switch interface.
- **Long Press** – Lock/unlock touch panel.



13.0 WARRANTY TERMS & CONDITIONS

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty is provided in addition to your rights under the Australian Consumer Law.

Directed Electronics Australia Pty Ltd (Directed Electronics) warrants that this product is free from defects in material and workmanship for a period of 12 months from the date of purchase or for the period stated on the packaging. This warranty is only valid where you have used the product in accordance with any recommendations or instructions provided by Directed Electronics.

This warranty excludes defects resulting from alterations of the product, accident, misuse, abuse or neglect. In order to claim the warranty, you must return the product to the retailer from which it was purchased or if that retailer is part of a National network, a store within that chain, along with satisfactory proof of purchase. The retailer will then return the goods to Directed Electronics.

Directed Electronics will repair, replace or refurbish the product at its discretion. The retailer will contact you when the product is ready for collection. All costs involved in claiming this warranty, including the cost of the retailer sending the product to Directed Electronics, will be borne by you.

Ph: +61 03 8331 4800 | Email: info@kapturecam.com.au

13.1 INDEMNITY

You agree to defend, indemnify and hold harmless KPT-W62B and its subsidiaries and affiliates from and against any and all claims, proceedings, injuries, liabilities, losses, costs and expenses (including reasonable legal fees), including but not limited to, claims alleging negligence, invasion of privacy, copyright infringement and/or trademark infringement against KPT-W62B and its subsidiaries and affiliates, relating to or arising out of your breach of any provision of these terms, your misuse of KPT-W62B products or its services, or your unauthorised modification or alteration of products or software.

13.2 WARRANTY AND WARRANTY DISCLAIMER

KPT-W62B has a limited warranty, whereby KPT-W62B warrants to you and only to you that this KPT-W62B product will be free from defects in materials and workmanship for one (1) year from the date of your purchase (unless a longer warranty period is required by law). The specifics of this KPT-W62B limited warranty are covered in this manual.

To the extent possible under governing law, other than the above product warranty for the KPT-W62B product you understand and agree that the KPT-W62B products and services are provided on an “as is” and “as available” basis. KPT-W62B makes no warranty that the KPT-W62B products and services will meet your requirements or that use of the KPT-W62B products and services will be uninterrupted, timely, secure or error-free. Nor does KPT-W62B make any warranty as to the accuracy or reliability of any information obtained through KPT-W62B (including third party content), that any defects in the KPT-W62B products or services be corrected or that the KPT-W62B products or KPT-W62B services will be compatible with any other specific hardware or service. Further, KPT-W62B does not warrant that KPT-W62B

products or services or KPT-W62B servers that provide you with data and content are free of viruses or other harmful components.

KPT-W62B also assumes no responsibility for and shall not be liable, for any damages caused by viruses that may infect your KPT-W62B product or software. In the event of any loss, damage or injury, you will not look to KPT-W62B to compensate you or anyone else.

You release and waive for yourself and your insurer all subrogation and other rights to recover against KPT-W62B arising as a result of the payment of any claim for loss, damage or injury. KPT-W62B equipment and services do not cause and cannot eliminate occurrences of certain events and KPT-W62B makes no guarantee or warranty, including any implied warranty of merchantability or fitness for a particular purpose or that KPT-W62B equipment and services provided will detect or avert such incidents or their consequences.

KPT-W62B does not undertake any risk that you or property, or the person or property of others, may be subject to injury or loss if such an event occurs. The allocation of such risk remains with you, not KPT-W62B. Other than the above product warranty for KPT-W62B products, its suppliers disclaim all warranties of any kind, whether express, implied, or statutory, regarding the KPT-W62B products and services, including any implied warranty of title, merchantability, fitness for a particular purpose, or non-infringement of third-party rights. Because some jurisdictions do not permit the exclusion of implied warranties, the last sentence of this section may not apply to you.

KPT-W62B hereby further expressly disclaims all liability for any claims for service failures that are due to normal product wear, product misuse, abuse, product modification improper product selection or your noncompliance with all applicable federal, state or local laws. This warranty and warranty disclaimer give you specific legal rights, and you may have other rights that vary

by state, province, or country. Other than as permitted by law, KPT-W62B does not exclude, limit or suspend other rights you have, including those that may arise from the nonconformity of a sales contract. For a full understanding of your rights, you should consult the laws of your state, province, or country.

13.3 LIMITATIONS OF KPT-W62B LIABILITY

Under no circumstances will KPT-W62B be liable in any way for any content, including, but not limited to, the loss of content, any errors or omissions in any content, or any loss or damage of any kind incurred in connection with use of or exposure to any content posted, emailed, accessed, transmitted, or otherwise made available via KPT-W62B. KPT-W62B liability for damages, especially for breach of duty or obligation, delay in performance, non-performance, or malperformance shall be precluded, except when these are due to negligent breaches of any significant contractual duty or obligation on the part of KPT-W62B. Any liability for negligence is limited to direct losses usually and typically foreseeable in such case.

Should the claim for damages be based on wilful or grossly negligent breach of contractual duty or obligation on the part of KPT-W62B, the preclusion and limitation of liability mentioned in the preceding sentences will not apply. The preceding preclusion and limitation of liability will also not apply to claims for damages arising out of loss of life, bodily injury or health impacts for which KPT-W62B may be liable, or for non-contractual liability.

Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Additionally, this provision is not intended to limit KPT-W62B's liability in the event of KPT-W62B's wilful or intentional misconduct.

Your Connection On The Road

www.kapturecam.com.au | www.kapturecam.co.nz



All Images, Information and Content are Copyright © 2025
Directed Electronics Australia Pty Ltd. All Rights Reserved.



www.directed.com.au
www.directed.co.nz